



- ⑤ EXISTING TO REMAIN.
- ① REMOVE EXISTING DOOR AND FRAME. PREP OPENING FOR NEW DRYWALL INFILL.
- ② CREATE OPENING IN PARTITION FOR NEW 3'-0" x 7'-0" HM CASSED OPENING.
- ③ REMOVE EXISTING DOOR AND FRAME. PREP OPENING FOR NEW HM DOOR/CASSED OPENING FRAME. SEE DOOR SCHEDULE.
- ④ REMOVE EXISTING PARTITION. PATCH AND REPAIR CEILING GRID/TILES AS REQ.
- ⑤ REMOVE EXISTING GLOW-IN-THE-DARK EXIST SIGN.



Copyright © 2025