

1. EXISTING UTILITY CONFLICTS TO REMAIN IN WALLS DESIGNATED TO REMAIN.
2. MODIFY THE EXISTING SPRINKLER AND FIRE ALARM SYSTEMS PER CODE.
 - UNDER SERVICE FLOORS.
3. EXISTING SUSPENDED CEILING TO REMAIN - REPLACE DAMAGED OR SOILED TILE WITH MATCHING ACCENTUAL TILE.

1. PROVIDE NEW BUILDING STANDARD FINISHES THROUGHOUT OFFICE AREA
2. COLOR SELECTION OF FINISHES BY TENDR
3. FINISH TYPE

- Ⓐ LOOP CARPET, RUBBER BASE AND PAINT FINISH ON WALLS.
- Ⓑ 12"X 12" 1/8" VCT, 4" RUBBER BASE AND PAINT FINISH ON WALLS
- Ⓒ NO NEW FINISHES THIS AREA.

[illegible]

2x 2' SUSPENDED CEILING AT 9'-0" A.M.P.

25. 4 LAMP IN 8 CELL FLUORESCENT PARABOLIC LIGHT FIXTURE
26. METAL HALIDE LIGHT FIXTURE - SEE ELEC. DRAWINGS
27. BAY SIGN WITH BATTERY PACK
28. EMERGENCY LIGHT FIXTURE WITH BATTERY PACK
29. COMMUNICATION PORT SIGN AND EMERGENCY LIGHT FIXTURE WITH BATTERY PACK
30. EXHAUST FAN TO EXTERIOR
31. SHIELD POLE LIGHT SWITCH
32. 8-WAY LIGHT SWITCH
33. LIGHT SWITCH ON DOWNER


EXISTING WALLS TO REMAIN

EXISTING CONSTRUCTION TO BE REMOVED


- ===== NEW STR. OR WALLS TO BOTTOM OF SHAR. CEILING HEIGHT
- ===== NEW STR. OR WALLS IN BATT WALL, TO BOTTOM OF ROOF STRUCTURE
- ² FIRE BATHWATER LOCATION
- DOOR TYPE - SEE DOOR NOTES
- ▽ PARTITION TYPE - SEE PARTITION NOTES
- FINISH TYPE - SEE FINISH NOTES
- X APPROXIMATE LOCATION OF LATERAL SUPPORT BEAMS OF WALL

1. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
2. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
3. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
4. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
5. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
6. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
7. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
8. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
9. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.
10. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING. REPAIR OR REPLACE THE CRACKED OR DAMAGED PART OF THE ROOF FLASHING.

SCALE: 1/8" = 1'-0"



SCALE: 1/8" = 1'-0"



SCALE, 1/8" = 1'-0"

NOV. 10, 2016	2
---------------	---

BATE TRUCKS PARTWAY
ROUTE 808
 MOHAWUCK, CINCINNATI, OHIO
 (770) 440-4804

FLOOR PLAN
AND
REFLECTED
CEILING PLAN

☐ REVIEW ONLY
☐ PRICING ONLY
☒ FOR CONSTRUCTION

A2